
ATRIUM® SP comfort

Mounting instructions – scheme C

GB

A13 Axial spacing 13 mm

with night vent function



The figures within these mounting instructions refer to HAUTAU version Left (*DIN EN 12519 Right*).

For HAUTAU versions Right (*DIN EN 12519 Left*) measures have to be applied correspondingly.

Note:

Scheme C with loose post EG 30/15 and trimmed 2nd sash requires that you install the size 1 stay system in the 2nd sash for sash rebate widths between FFB 900 and FFB 920.

For the installation of the stay systems ㉖ see installation instructions ATRIUM® SP comfort, item no.: 234991

Contents

page

Mounting of strikers, scheme C 2

Horizontal sections scheme C 3

Abbreviations

FFB	Sash rebate width
FB	Sash width
FG	Sash weight
FFH	Sash rebate height
FFK	Sash rebate edge

All measurements in these instructions are indicated in millimetres (mm).

Mounting of strikers, scheme C

Mounting sequence for frames

in case of lack of space:


A - insert both stay systems (26) and the guide block (48a) laterally into guide tracks (35). Mind 1-/2-sash arrangement.
- Attach cover caps (41) on ends of guide tracks.
- Tighten guide track at frame with screws 4.0 x ...
Refer to section "Mounting of guide track", too.

B Fix strikers (13)/(13b) according to chart.

All measurements mentioned below are valid for 12 mm fittings cavity.

To use:

‹4,0 x ...




FFB	Y1	Y2	Z1	Z2
751 ... 900	400	–	381	–
901 ... 1050	492	–	473	–
1051 ... 1250	642	–	623	–
1251 ... 1450	292	892	273	873
1451 ... 1650	492	1092	473	1073

FFH	U	V	W	X
650 ...1000	90[1)]	–	90[1)]	–
1001 ...1450	–	110[2)]	–	110[2)]
1451 ... 2350	309	341	309	341

[1)] *for gear size 110*
[2)] *for gear size 140*


* *tightening torque refer to page 15 „Installation of guide block" installation instructions ATRIUM® SP comfort, item no.: 234991*

Horizontal sections
scheme C




**) identification of X: refer to page 9, "Mounting of bogies", fig. 1*


Type 1: uPVC – with loose post EG 15/15
(special striker required)



Type 2: uPVC – with loose post EG 15/15u



Type 3: uPVC – with loose post EG 30/15, sash **2** trimmed



Type 4: Timber – without post with open groove EG 30/30

